

*a measurable difference...*



## Coefficient of Friction Tester Incline Plane

### Model: C0045

This instrument is used to determine the coefficient of static friction of most packaging materials by measuring the angle at which one test surface begins to slide against another inclined surface as the incline is increased at a constant and prescribed rate. As the plane rises at a rate of  $1.5^{\circ} \pm 0.5^{\circ}/s$ , the first sign of movement from the sled is detected by a micro switch, stopping the plane movement and recording the relevant angle of the incline. The test is frequently referred to as a slide angle. The coefficient of friction is numerically equivalent to the tangent of that angle.

### Applications:

- Paper
- Plastics
- Film
- Foil
- Coatings

### Features:

- Motor driven
- Angle Inclination:  $0 - 60^{\circ}$
- Angle Indication:  $0.1^{\circ}$

### Standards:

- ASTM D202
- TAPPI T815
- TAPPI T548

### Options:

- Sled: 90mm x 100mm, 1300g
- Sled: 63.1mm x 63.1mm, 200g
- Cutting Template - Plane: 130 x 140mm
- Cutting Template - 1300g Sled: 93 x 160mm
- Cutting Template - 200g Sled: 66.5 x 100mm

### Connections:

- **Electrical:** 220/240 VAC @ 50 HZ or  
110 VAC @ 60 HZ  
(please specify when ordering)

### Dimensions:

- **H:** 130mm    • **W:** 260mm    • **D:** 210mm
- **Weight:** 5kg



10-11 Colrado Court, Hallam, Victoria 3803 Australia.

Phone: +61 3 9708 6885

Fax: +61 3 9708 6770

Website: [www.idminstruments.com.au](http://www.idminstruments.com.au)

Email: [idm@idminstruments.com.au](mailto:idm@idminstruments.com.au)

All sizes and dimensions shown on this data sheet are averages only and images are as accurate as the medium allows. Products and details shown may change without notice as IDM Instruments Pty Ltd<sup>®</sup> reserves the right to make alterations to its product range from time to time.

Copyright © 2006 IDM Instruments Pty Ltd<sup>®</sup>. All Rights Reserved.