

a measurable difference...



Ink Rub Tester

Model: I0001

The Ink Rub Tester is designed to determine the quality of adhesion, and scuff resistance of ink to paper surfaces, plastic and aluminium film. The motorised unit is simple to operate by entering the number of rubs in the pre-set counter and starting the unit. It will rub the sample until the pre-set value is achieved. Dry and Wet rub can be performed on the Ink Rub Tester.

The method of operation is that a 2 or 4 Lb weight with a clean white board is swept across the test piece for a set number of times, then closely examined.

Application:

- Printed Carton board
- Printed Corrugated board
- Paper
- Plastics
- Aluminium Film

Features:

- Two Speeds - 42 and 85 cpm
- Fast Testing
- 2 lb and 4 lb weights
- Counter 0-9999
- 1 Creasing Board
- 1 Creasing Tool
- Cutting templates
Sample: 152 x 51mm
Base: 152 x 76mm

Options:

- Heated Weights 2 lb or 4 lb
- Ambient to 150°C
- Standard BS 3110: 1959- Method 1

Standards:

- TAPPI T830
- ASTM D5264



Connections:

- **Electrical:** 220/240 VAC @ 50 HZ or 110 VAC @ 60 HZ
(please specify when ordering)

Dimensions:

- **H:** 230mm
- **W:** 310mm
- **D:** 200mm
- **Weight:** 12kg

10-11 Colrado Court, Hallam, Victoria 3803 Australia.

Phone: +61 3 9708 6885

Fax: +61 3 9708 6770

Website: www.idminstruments.com.au

Email: idm@idminstruments.com.au

All sizes and dimensions shown on this data sheet are averages only and images are as accurate as the medium allows. Products and details shown may change without notice as IDM Instruments Pty Ltd[®] reserves the right to make alterations to its product range from time to time.