

*a measurable difference...*



## Master Screen

The Pulmac Master Screen is a low consistency screening device designed to mechanically separate shives, dirt and/or stickies from fiber. After screening, the contaminants are washed directly onto a filter paper, and water is removed by the Auto-Filter's vacuum-assist drain system. The master screen provides a rapid and repeatable method for concentrating and collecting shives, stickies and/or dirt.

### Application:

- Pulp

### Features:

- CE Compliant
- Screens up to 100 grams (oven dried equivalent)
- Results in 5 to 10 minutes
- Standard screen plates available with 100 or 150 micron slots
- Auto Filter to rapidly display reject contaminants
- Three distinct test cycles to match sample size and screenability

### Standards:

- TAPPI T274

### Connections:

- Air
- Electrical: 220/240 VAC @ 50 HZ or  
115 VAC @ 60 HZ

*(please specify when ordering)*



10-11 Colrado Court, Hallam, Victoria 3803 Australia.

Phone: +61 3 9708 6885

Fax: +61 3 9708 6770

Website: [www.idminstruments.com.au](http://www.idminstruments.com.au)

Email: [idm@idminstruments.com.au](mailto:idm@idminstruments.com.au)

All sizes and dimensions shown on this data sheet are averages only and images are as accurate as the medium allows. Products and details shown may change without notice as IDM Instruments Pty Ltd<sup>®</sup> reserves the right to make alterations to its product range from time to time.

Copyright © 2006 IDM Instruments Pty Ltd<sup>®</sup>. All Rights Reserved.