

a measurable difference...



Pail Measuring Instrument

Model: P0009

The Pail Measuring Instrument is manufactured with two recesses, one for 10 to 20 litre pails on the left-side, and 1 to 10 litre pails on the right side. The pail is placed in the measuring recess of the unit, the operator can switch a toggle switch to activate measuring on either one of the measuring recesses.

The measuring band contracts via a pneumatic cylinder to a pre-determined pressure, set on the regulator.

The instrument will display the measurement in mm once the cylinder has stopped moving.

Where the operator can take the measurement there are two indicators, A and B, for each range of pail sizes. To release the pail it is a simple matter of switching the toggle switch in the opposite direction and the band will return to its original position.



Application:

- Plastic pail lid
- Plastic pails

Features:

- 1 - 10 and 10 - 20 Litre Pails and Lids
- Accuracy:- 0.10 mm
- Repeatability:- 0.30 mm
- Readability:- 0.1 mm
- Measuring type:- Spring Steel Band
- Adjustable Air Pressure
- Peak Reading Display
- 2 x Check Rings
- 2 x Weights

Standards:

- N/A

Options:

- N/A

Connections:

- **Air Supply:** 80psi
- **Electrical:** 220/240 VAC @ 50 HZ or 110 VAC @ 60 HZ

(please specify when ordering)

Dimensions:

- **H:** 800mm
- **W:** 750mm
- **D:** 500mm
- **Weight:** 60kg

10-11 Colrado Court, Hallam, Victoria 3803 Australia.

Phone: +61 3 9708 6885

Fax: +61 3 9708 6770

Website: www.idminstruments.com.au

Email: idm@idminstruments.com.au

All sizes and dimensions shown on this data sheet are averages only and images are as accurate as the medium allows. Products and details shown may change without notice as IDM Instruments Pty Ltd[®] reserves the right to make alterations to its product range from time to time.