

When quality matters

Technidyne is there



The TEST/Plus™ product line brings standardized testing to the market in an affordable and cost competitive design. Providing you control of what you test and how you test it, while enhancing your quality programs capabilities.



The Technidyne TEST/Plus™ Gloss combines industry standardized measurement technology with an innovative control package that allows the user to tailor build their testing and evaluation capabilities. This new addition to the TEST/Plus™ product line is built to meet your Gloss testing needs;

When quality matters, Technidyne is there.



TEST/Plus™ Gloss

- Measurements in seconds
- Configured to measure 75° gloss or 20° gloss
- Adaptive Interface Technology
- Continuous mode operation for sample testing
- Easy-To-Use Operator Interface

TEST/PLUS™

At the core of the TEST/Plus™ Gloss are a series of specially developed APPS that allow for complete control of your data and how you interface with the instrument and your operation.

Print App

- for hard copy of the data

Averaging and Statistics App

- for statistical analysis

Export App

- for getting the data to the DCS

Database App

- for managing data on the instrument





TEST/PLUS™ gloss

Adaptive Interface Technology



Specifications and Technical Data

TEST/Plus Gloss Specifications

Parameter	Specification	Parameter	Specification
Industry Standardization	Choose appropriate angle of measurement/application	Light Source	Quartz Tungsten Halogen
Paper & Packaging	TAPPI T 480 - 75° TAPPI T 653 - 20°	Measurement Time	< 2 seconds
Measurement Range	0 - 100 % on TAPPI Gloss Scale	Data Communications	Wifi, Ethernet, USB
Measurement Units	% Gloss	Optional Operational APPs	Averaging and Statistics Print Data Export Database
Effective Wavelength	572 nm	Operating Temperature	10-32 degrees Celsius
Spectral Response	CIE Y _A function	Depth	14" / 35.6 cm
Geometry	75° illumination / 75° viewing 20° illumination / 20° viewing	Width	9" / 23 cm
Sample Aperture / Sample Area of View	34.9 mm x 25.4 mm 19.3 mm x 10 mm	Height	16" / 38 cm
Spectral Match Bandwidth	± 0.5 nm	Power Consumption	170 watt max / 80 watts passive
Calibration Standards	Traceable to Technidyne /NBS calibration standards	Voltage / Frequency	100 - 230 VAC / 48-61
Accuracy to TAPPI Method	± 0.3 %	USB Port	1
Repeatability	± 0.1 %	Foot Switch Measurement	Optional
Reproducibility	± 0.5 %		

Optimizing your processes is the goal of any manufacturing environment. The Technidyne TEST/Plus™ ISO Gloss provides a tool for the effective evaluation of your processes. Once accurate evaluations are established, then process control parameters can be set. The TEST/Plus™ Gloss can be counted on to be that repeatable evaluation tool to help you optimize your system. When the process has to be right, you need the right tools.

With the TEST/Plus™ ISO Gloss you can make it right the first time.



When quality matters, Technidyne is there